



In-Swing Doors

1. Walk inside stall.
2. Bump door shut with hip, elbow, foot, etc. Door will hold in closed position
3. Wave hand to lock door.
4. When ready to leave, wave hand again; latch will unlock and door will swing open automatically.

Out-Swing Doors

1. Approach out-swing stall and use arm pull to open door. Enter.
2. Wave hand to lock door once it is in the closed position.
3. When ready to leave, Wave hand again. the latch will unlock and the user may simply bump the door open with elbow, hip or foot during exit.

* Out-swing doors are almost always accessible stalls that meet ADA requirements. ADA code states the door must tend to the closed position.

Maintenance

Batteries

- Battery Type: 4 AAs
- Low Battery: LED will blink slowly when batteries are running low
- Change Batteries once a year or when LED begins to blink. Loosen battery cover fastener. Remove Cover. Remove battery holder. Replace batteries. Reinsert batteries. Fasten battery cover.

Adjust Keeper Distance

- If the door shifts overtime you may need to adjust the keeper.
- Loosen the tightening bolt and shift keeper to proper position.
- Proper position for an in-swing door: where an in-swing door will remain closed when shut AND will also fully release and automatically swing open when unlocked.
- Proper position for an out-swing door: where an out-swing door will fully shut via gravity hinges and sufficiently lock.